A Powerful and Easy to Use Lockbox

Easy to use correctly, hard to use incorrectly

Lab7

Easy to Use Correctly: NaCl "box" concept

Remember

There is no 100% security

Security, like all engineering, involves tradeoffs

Know what you are trying to secure


The adversary...





Network Configuration

Simple Network for this Lab



1Hz : 1 Hz generators of J1939 messages

MitM: Man-in-the-Middle

ECU : ECU added (& controlled) by student

TIC: Text Instrument Cluster

tool(s): One or more of can-utils (canplayer, candump, cansniffer, etc.)

adapter A: security adapter that validates secure messages before

passing them to the TIC for decoding

adapter B : security adapter that secures messages before sending them

on the bus

required

optional

Notes

Complexity is the enemy of security.

- Bruce Schneier

TweetNaCl demonstrates a full library in 100 tweets.

- All elliptic curve code
- All encryption and hashing code

NaCl – easy to use correctly, hard to use incorrectly


"Box"

To secure data being sent from Entity A to Entity B.

- Data
- Nonce (which *must* be shared with Entity B)
- Entity A private key
- Entity B public key

nonce Data, N bytes


Box(data, nonce, P_B, K_A)



"Box"

To secure data being sent from Entity A to Entity B.


• Every time data is sent, a <u>new nonce is required</u>.



"BoxOpen"

To validate and decrypt data being sent from Entity A to Entity B.

- "box" (mac || ct)
- Nonce (which was provided by Entity A)
- Entity A public key
- Entity B private key



Notes

• Every library seems to label the functions a little differently

- In "TweetNaCl" the functions are very straightforward:
 - nacl.box()
 - nacl.boxopen()

• In python library it takes a couple of steps.

```
> cat -n using nacl.py
                           #
                        1
                        2 # reference:
                           # https://pynacl.readthedocs.io/en/latest/public/#nacl-public-box
      Notes
                        5 import nacl.utils
                           from nacl.public import PrivateKey, Box
                          # notes on key naming
                          # P/Kx -- Public/Private keypair for entity x
Used to put data
                                   -- Symmetric key for entity x
                       10
                          # Sx
                       11
into box and get
                       12 # Generate Bob's private key (!! keep this secret !!)
                           Kb = PrivateKey.generate()
                       14
                       15 # Use the private key to create the public key -- this must be shared
                           Pb = Kb.public key
                       16
                       17
                       18 # Alice does the same thing
                       19 Ka = PrivateKey.generate()
                           Pa = Ka.public key
                       21
                       22 # <here Alice and Bob exchange public keys>
                       23
                           # Bob wants to box some data for Alice:
                       25 # He needs his private key and Alice's public key
                       <del>26 →</del> boxerBA = Box(Kb, Pa)
                       27
```

it out.

Notes

```
data = bytes.fromhex("00000000 11111111 22222222 33333333")
                            print("data to secure")
                            print(data.hex(" ", 4))
                        31
'encrypt' puts
                            # the library automatically created a nonce for us.
data into box
                            # using boxerBA results in a box that is:
                            # mac || nonce || data === 16 bytes || 24 bytes || len(data)
                            # so total length is 40 bytes longer than data
                            box = boxerBA.encrypt(data)
                         37
                        38
                            ### Alice is given the box, 'box', and needs to open it.
                         39
                        40
                            # create a box opener, she uses Bob's public key and her private key
                             boxopenerBA = Box(Ka, Pb)
  'decrypt'
                        43
  unboxes the data
                            # use the opener
                            pt = boxopenerBA.decrypt(box)
                        46
                                                                         > python3 using nacl.py
                            print("data received by Alice")
                                                                         00000000 11111111 2222222 33333333
                            print(pt.hex(" ", 4))
                                                                         data received by Alice
                                                                         00000000 11111111 2222222 33333333
```

Lab

- The only code required is for:
 - adapterA.py
 - adapterB.py

Lab

nonce

